















**Teknorot Inquiry List**  
08/18/2020

Product Image	Teknorot Ref No	Product Group	Compatible Vehicles	Position	OEM Code	Quantity
	<a href="#">SC 86</a>	Engine Mount Bushing	<a href="#">FIAT PALIO - SIENA 1996-2013</a> <a href="#">FIAT ALBEA 1996-2013 &amp; 178</a>	Front	46833123	10
	<a href="#">SC 90</a>	Engine Mount Bushing	<a href="#">FIAT UNO 1983-2001 &amp; (146A/E)</a>	Front	7667850	10
	<a href="#">SC 87</a>	Engine Mount Bushing	<a href="#">FIAT PALIO - SIENA 1996-2013</a>	Front	46439600	10
	<a href="#">SC 91</a>	Engine Mount Bushing	<a href="#">FIAT UNO 1983-2001 &amp; (146A/E)</a>	Rear	5937315	10
	<a href="#">SC 92</a>	Engine Mount Bushing	<a href="#">FORD FOCUS 1998-2004 &amp; I europe made</a>	Right	1105977, 98AB6038CH, 1139257	10
	<a href="#">SC 96</a>	Engine Mount Bushing	<a href="#">FORD TRANSIT 1987-1992</a>	Front	7242755	10

Product Image	Teknorot Ref No	Product Group	Compatible Vehicles	Position	OEM Code	Quantity
	<a href="#">SC 98</a>	Engine Mount Bushing	<a href="#">OPEL RECORD 1977-1986 &amp; ( E ) (Year Only: 1978-1986)</a>	Front	684241	10
	<a href="#">SC 89</a>	Engine Mount Bushing	<a href="#">FIAT UNO 1983-2001 &amp; (146A/E)</a>	Front	7646680	10
	<a href="#">SC 9</a>	Engine Mount Bushing	<a href="#">VOLKSWAGEN GOLF 1983-1992 &amp; MK2/A2</a> <a href="#">VOLKSWAGEN PASSAT 1980-1988 &amp; B2</a>	Front	191199279B, 191199279D, 191199279C	10
	<a href="#">SC 115</a>	Engine Mount Bushing	<a href="#">PEUGEOT 206 1998-2008</a>	Front Right Upper	1844.A2, 1844.A7	10
	<a href="#">SC 116</a>	Engine Mount Bushing	<a href="#">PEUGEOT 206 1998-2008</a>	Front	1844.73, 1844.A1	10
	<a href="#">SC 117</a>	Engine Mount Bushing	<a href="#">RENAULT CLIO 1998-2012 &amp; II-SYMBOL</a>	Right	8200267625	10
	<a href="#">SC 118</a>	Engine Mount Bushing	<a href="#">RENAULT CLIO 1998-2012 &amp; II-SYMBOL</a>	Rear	7700415095	10
	<a href="#">SC 120</a>	Engine Mount Bushing	<a href="#">RENAULT CLIO 1990-1998 &amp; I</a>	Right	7700795687	10

Product Image	Teknorot Ref No	Product Group	Compatible Vehicles	Position	OEM Code	Quantity
	<a href="#">SC 121</a>	Engine Mount Bushing	<a href="#">RENAULT CLIO 1990-1998 &amp; I</a>	Left	7700795688	10
	<a href="#">SC 123</a>	Engine Mount Bushing	<a href="#">RENAULT LAGUNA 2001-2007 &amp; II</a>	Right	7700414099	10
	<a href="#">SC 124</a>	Engine Mount Bushing	<a href="#">RENAULT LAGUNA 1993-2001 &amp; I</a>	Front Right	7700823950	10
	<a href="#">SC 125</a>	Engine Mount Bushing	<a href="#">RENAULT LAGUNA 1993-2001 &amp; I</a>	Rear	7700422529	10
	<a href="#">SC 126</a>	Engine Mount Bushing	<a href="#">RENAULT LAGUNA 1993-2001 &amp; I</a>	Right	7700423007	10
	<a href="#">SC 127</a>	Engine Mount Bushing	<a href="#">OPEL MOVANO 1998-2010 &amp; ( A )</a> <a href="#">RENAULT MASTER 1998-2003 &amp; I</a>	Rear	7700308756	10
	<a href="#">SC 129</a>	Engine Mount Bushing	<a href="#">OPEL MOVANO 1998-2010 &amp; ( A )</a> <a href="#">RENAULT MASTER 1998-2003 &amp; I</a>	Right	8200022595	10

Product Image	Teknorot Ref No	Product Group	Compatible Vehicles	Position	OEM Code	Quantity
	<a href="#">SC 130</a>	Engine Mount Bushing	<a href="#">OPEL MOVANO 1998-2010 &amp; ( A )</a> <a href="#">RENAULT MASTER 1998-2003 &amp; I</a>	Left	8200199149	10
	<a href="#">SC 132</a>	Engine Mount Bushing	<a href="#">RENAULT MEGANE 2003-2009 &amp; II</a>	Rear	8200014933	10
	<a href="#">SC 133</a>	Engine Mount Bushing	<a href="#">RENAULT MEGANE 1995-2003 &amp; I</a> <a href="#">RENAULT KANGOO 1998-2008 &amp; I</a>	Rear	7700100116, 8200148388, 7700432031	10
	<a href="#">SC 134</a>	Engine Mount Bushing	<a href="#">RENAULT 19 1991-2001</a> <a href="#">RENAULT CLIO 1998-2012 &amp; II-SYMBOL</a> <a href="#">RENAULT EXPRESS 1985-1998 &amp; EXTRA(VAN)</a> <a href="#">RENAULT KANGOO 1998-2008 &amp; I</a>	Rear	7700424321, 7700800522	10
	<a href="#">SC 131</a>	Engine Mount Bushing	<a href="#">RENAULT MEGANE 2003-2009 &amp; II</a>	Rear	7700832264	10

Product Image	Teknorot Ref No	Product Group	Compatible Vehicles	Position	OEM Code	Quantity
	<a href="#">SC 10</a>	Engine Mount Bushing	<a href="#">VOLKSWAGEN TRANSPORTER 1979-1992 &amp; T3</a>	Front	251199201G	10
	<a href="#">SC 102</a>	Engine Mount Bushing	<a href="#">FORD TRANSIT 1992-2000 &amp; (T12,T15)</a>	Rear	6177036, 88VB6068AB	10
	<a href="#">SC 103</a>	Engine Mount Bushing	<a href="#">HONDA CIVIC 1996-2001 &amp; VI</a> <a href="#">MITSUBISHI LANCER 1996-2001 &amp; VI</a>	Right	50842SR3030	10
	<a href="#">SC 104</a>	Engine Mount Bushing	<a href="#">HYUNDAI ACCENT 1994-2000 &amp; I</a> <a href="#">HYUNDAI PONY EXCEL 1994-2000 &amp; III</a> <a href="#">MITSUBISHI LANCER 1996-2001 &amp; VI</a>	Front	2184022300	10
	<a href="#">SC 105</a>	Engine Mount Bushing	<a href="#">MITSUBISHI L300 1986-2006</a>	Right	2181243200, MB436833	10
	<a href="#">SC 107</a>	Engine Mount Bushing	<a href="#">PEUGEOT 206 1998-2008</a>	Right	1844.75*	10
	<a href="#">SC 109</a>	Engine Mount Bushing	<a href="#">PEUGEOT 405 1985-1997</a> <a href="#">PEUGEOT 605 1985-1997</a> <a href="#">PEUGEOT 806 1985-1997</a>	Left	1827.16	10

Product Image	Teknorot Ref No	Product Group	Compatible Vehicles	Position	OEM Code	Quantity
	<a href="#">SC 110</a>	Engine Mount Bushing	<a href="#">CITROEN JUMPY 1995-2003 &amp; EVANSION</a> <a href="#">PEUGEOT 406 1995-2004</a>	Front	1806.28, 9631575180	10
	<a href="#">SC 111</a>	Engine Mount Bushing	<a href="#">PEUGEOT J5 1981-1985</a>	Rear	1843.6	10
	<a href="#">SC 112</a>	Engine Mount Bushing	<a href="#">PEUGEOT J5 1981-1985</a> <a href="#">FIAT DUCATO 1981-1994</a>	Left	1843.8	10
	<a href="#">SC 113</a>	Engine Mount Bushing	<a href="#">PEUGEOT J9 1980-1987</a>	Front	1807.15	10
	<a href="#">SC 37</a>	Engine Mount Bushing	<a href="#">RENAULT MEGANE 1993-2001 &amp; I</a> <a href="#">RENAULT LAGUNA 1993-2001 &amp; I</a>	Front	7700832256	10
	<a href="#">SC 38</a>	Engine Mount Bushing	<a href="#">RENAULT MEGANE 1995-2003 &amp; I</a>	Right	7700425757, 7700437391	10
	<a href="#">SC 39</a>	Engine Mount Bushing	<a href="#">RENAULT CLIO 1998-2012 &amp; II-SYMBOL</a> <a href="#">RENAULT KANGOO 2008- &amp; II</a>	Front Right	7700415089, 7700434370	10


Product Image	Teknorot Ref No	Product Group	Compatible Vehicles	Position	OEM Code	Quantity
	<a href="#">SC 4</a>	Engine Mount Bushing	<a href="#">SEAT TOLEDO 1993-1999 &amp; I (1L)</a> <a href="#">VOLKSWAGEN GOLF 1991-1998 &amp; MK3/A3</a> <a href="#">VOLKSWAGEN PASSAT 1988-1997 &amp; B3, B4</a> <a href="#">VOLKSWAGEN POLO CLASSIC 1995-2001</a>	Rear Left	357199402B	10
	<a href="#">SC 40</a>	Engine Mount Bushing	<a href="#">RENAULT MEGANE 1995-2003 &amp; I</a>	Rear	7700849715	10
	<a href="#">SC 41</a>	Engine Mount Bushing	<a href="#">RENAULT 19 1991-2001</a>	Front Right	7700802927	10
	<a href="#">SC 43</a>	Engine Mount Bushing	<a href="#">RENAULT CLIO 1998-2012 &amp; II-SYMBOL</a> <a href="#">RENAULT MEGANE 1995-2003 &amp; I</a>	Rear	7700437854, 8200171178, 8200117837	10
	<a href="#">SC 44</a>	Engine Mount Bushing	<a href="#">RENAULT CLIO 1990-1998 &amp; I</a> <a href="#">RENAULT EXPRESS 1990-1998 &amp; I</a>	Front Left	7700795689, 7700795731	10
	<a href="#">SC 47</a>	Engine Mount Bushing	<a href="#">OPEL ASTRA-ZAFIRA 1998-2004</a> <a href="#">OPEL CORSA-COMBO 2000-2006 &amp; C</a>	Front Left	684661, 684671, 684665	10
	<a href="#">SC 48</a>	Engine Mount Bushing	<a href="#">OPEL CORSA-COMBO 1993-2000 &amp; (B)</a> <a href="#">OPEL CORSA-TIGRA 1999-2000</a> <a href="#">OPEL CORSA 1982-1993 &amp; ( A )</a>	Rear	682600, 90538063, 682603	10
	<a href="#">SC 49</a>	Engine Mount Bushing	<a href="#">OPEL ASTRA-ZAFIRA 1998-2004</a>	Front Right	5684051	10









Product Image	Teknorot Ref No	Product Group	Compatible Vehicles	Position	OEM Code	Quantity
	<a href="#">SC 5</a>	Engine Mount Bushing	<a href="#">OPEL OMEGA 1986-1994 &amp; ( A )</a>	Rear	402935, 90250986	10
	<a href="#">SC 50</a>	Engine Mount Bushing	<a href="#">OPEL ASTRA-ZAFIRA 1998-2004</a>	Front	684694	10
	<a href="#">SC 51</a>	Engine Mount Bushing	<a href="#">OPEL ASCONA 1981-1988 &amp; ( C )</a> <a href="#">OPEL VECTRA-CALIBRA 1988-1995 &amp; ( A )</a>	Front Left	684285, 90279258	10
	<a href="#">SC 55</a>	Engine Mount Bushing	<a href="#">CITROEN BERLINGO 1996- &amp; MF</a> <a href="#">CITROEN XSARA 1997-2005</a> <a href="#">CITROEN ZX 1991-1997</a> <a href="#">PEUGEOT PARTNER 1996- &amp; I</a>	Front Right	1844.47	10
	<a href="#">SC 56</a>	Engine Mount Bushing	<a href="#">CITROEN AX 1986-1991</a> <a href="#">PEUGEOT 106 1991-2004</a> <a href="#">PEUGEOT 205 1983-1998</a> <a href="#">PEUGEOT 306 1993-2001</a> <a href="#">PEUGEOT 405 1985-1997</a> <a href="#">CITROEN SAXO 1996-2003</a>	Right	1843.92, 91538407, 1844.72, 1844.38	10
	<a href="#">SC 46</a>	Engine Mount Bushing	<a href="#">RENAULT KANGOO 1998-2008 &amp; I</a>	Rear	7700415088, 7700426193	10



Product Image	Teknorot Ref No	Product Group	Compatible Vehicles	Position	OEM Code	Quantity
	<a href="#">SC 58</a>	Engine Mount Bushing	<a href="#">CITROEN AX 1986-1991</a> <a href="#">CITROEN SAXO 1996-2003</a> <a href="#">PEUGEOT 106 1991-2004</a> <a href="#">PEUGEOT 205 1983-1998</a> <a href="#">PEUGEOT 305 1984-1990</a> <a href="#">PEUGEOT 306 1993-2001</a> <a href="#">PEUGEOT 405 1985-1997</a> <a href="#">PEUGEOT 406 1995-2004</a>	Left	1843.82, 1843.95	10
	<a href="#">SC 6</a>	Engine Mount Bushing	<a href="#">VOLKSWAGEN GOLF 1983-1992 &amp; MK2/A2</a> <a href="#">VOLKSWAGEN PASSAT 1988-1997 &amp; B3, B4</a>	Right	191199262A	10
	<a href="#">SC 68</a>	Engine Mount Bushing	<a href="#">FIAT 124 1966-1975 &amp; SPECIAL</a>	Front	4305266	10
	<a href="#">SC 7</a>	Engine Mount Bushing	<a href="#">VOLKSWAGEN GOLF 1983-1992 &amp; MK2/A2</a>	Rear Left	191199402C	10
	<a href="#">SC 70</a>	Engine Mount Bushing	<a href="#">BMW 3-SERIES 1982-1994 &amp; E30</a>	Front	11811129286	10




Product Image	Teknorot Ref No	Product Group	Compatible Vehicles	Position	OEM Code	Quantity
	<a href="#">SC 71</a>	Engine Mount Bushing	<a href="#">CITROEN AX 1986-1991</a> <a href="#">CITROEN BERLINGO 1986-1991</a> <a href="#">PEUGEOT 106 1986-1991</a> <a href="#">PEUGEOT 206 1986-1991</a> <a href="#">PEUGEOT 306 1986-1991</a> <a href="#">CITROEN SAXO 1986-1991</a> <a href="#">PEUGEOT 307 2000-2008</a>	Front Left	1844.51	10
	<a href="#">SC 78</a>	Engine Mount Bushing	<a href="#">OPEL VECTRA-CALIBRA 1988-1995 &amp; (A)</a>	Front Right	684646	10
	<a href="#">SC 8</a>	Engine Mount Bushing	<a href="#">VOLKSWAGEN GOLF 1991-1998 &amp; MK3/A3</a> <a href="#">VOLKSWAGEN PASSAT 1988-1997 &amp; B3, B4</a>	Rear Left	357199402C	10
	<a href="#">SC 80</a>	Engine Mount Bushing	<a href="#">FIAT DOBLO 2001-2010 &amp; 119</a>	Rear	46767476	10
	<a href="#">SC 82</a>	Engine Mount Bushing	<a href="#">CITROEN JUMPER 2002-2006 &amp; II</a> <a href="#">FIAT DUCATO 2002-2006 &amp; 14Q-1.8Q</a> <a href="#">PEUGEOT BOXER 2002-2005 &amp; ( 1.4Q-1.8Q )</a>	Right Upper	1335124080, 1807.T1	10
	<a href="#">SC 83</a>	Engine Mount Bushing	<a href="#">CITROEN JUMPER 2002-2006 &amp; II</a> <a href="#">FIAT DUCATO 2002-2006 &amp; 14Q-1.8Q</a> <a href="#">PEUGEOT BOXER 2002-2005 &amp; ( 1.4Q-1.8Q )</a>	Right	1335127080, 1839.A6	10
	<a href="#">SC 215</a>	Engine Mount Bushing	<a href="#">OPEL VIVARO 2001-2014 &amp; I</a> <a href="#">RENAULT TRAFIC 2001-2014 &amp; II</a>	Right	8200003827	10

Product Image	Teknorot Ref No	Product Group	Compatible Vehicles	Position	OEM Code	Quantity
	<a href="#">SC 216</a>	Engine Mount Bushing	<a href="#">OPEL VIVARO 2001-2014 &amp; I</a> <a href="#">RENAULT TRAFIC 2001-2014 &amp; II</a>	Right	8200003825, 8200378211	10
	<a href="#">SC 219</a>	Engine Mount Bushing	<a href="#">OPEL VIVARO 2001-2014 &amp; I</a> <a href="#">RENAULT TRAFIC 2001-2014 &amp; II</a>	Rear Right	8200003826	10
	<a href="#">SC 223</a>	Engine Mount Bushing	<a href="#">RENAULT CLIO 2005-2012 &amp; III-HB</a> <a href="#">RENAULT MODUS 2004-2014</a>	Right	8200239893, 8200487916	10
	<a href="#">SF 050</a>	Engine Mount Bushing	<a href="#">CITROEN ZX 1991-1997</a> <a href="#">PEUGEOT 305 1997-2005</a> <a href="#">PEUGEOT 306 1997-2005</a> <a href="#">CITROEN BERLINGO 1996- &amp; MF</a> <a href="#">PEUGEOT 406 1997-2005</a> <a href="#">CITROEN XSARA 1997-2005</a>	Right	1844.25	10
	<a href="#">SC 224</a>	Engine Mount Bushing	<a href="#">RENAULT CLIO 2005-2012 &amp; III-HB</a> <a href="#">RENAULT MODUS 2004-2014</a>	Right	8200131305, 8200140431	10
	<a href="#">SC 225</a>	Engine Mount Bushing	<a href="#">RENAULT CLIO 2005-2012 &amp; III-HB</a> <a href="#">RENAULT MEGANE 2003-2009 &amp; II</a> <a href="#">RENAULT MODUS 2004-2014</a> <a href="#">RENAULT SCENIC 2003-2009 &amp; II</a>	Rear	8200338385	10
	<a href="#">SF 27</a>	Engine Mount Bushing	<a href="#">RENAULT CLIO 1998-2012 &amp; II-SYMBOL</a>	Rear	7700426193	10

Product Image	Teknorot Ref No	Product Group	Compatible Vehicles	Position	OEM Code	Quantity
	<a href="#">SF 30</a>	Engine Mount Bushing	<a href="#">RENAULT MEGANE 2003-2009 &amp; II</a>	Rear	8200035448	10
	<a href="#">SC 23</a>	Engine Mount Bushing	<a href="#">VOLKSWAGEN GOLF 1974-1984 &amp; MK1/A1</a>	Right	171199214D	10
	<a href="#">SC 231</a>	Engine Mount Bushing	<a href="#">RENAULT SCENIC 2003-2009 &amp; II</a> <a href="#">RENAULT MEGANE 2003-2009 &amp; II</a>	Front Right	8200014931	10
	<a href="#">SC 232</a>	Engine Mount Bushing	<a href="#">RENAULT MEGANE 2003-2009 &amp; II</a> <a href="#">RENAULT SCENIC 2003-2009 &amp; II</a>	Right	8200549046	10
	<a href="#">SC 233</a>	Engine Mount Bushing	<a href="#">RENAULT CLIO 2005-2012 &amp; III-HB</a> <a href="#">RENAULT MEGANE 2003-2009 &amp; II</a> <a href="#">RENAULT MODUS 2004-2014</a> <a href="#">RENAULT SCENIC 2003-2009 &amp; II</a>	Rear	8200042453	10
	<a href="#">SC 237</a>	Engine Mount Bushing	<a href="#">RENAULT MEGANE 2003-2009 &amp; II</a> <a href="#">RENAULT SCENIC 2003-2009 &amp; II</a>	Lower	8200042454	10
	<a href="#">SC 238</a>	Engine Mount Bushing	<a href="#">RENAULT MEGANE 2003-2009 &amp; II</a> <a href="#">RENAULT SCENIC 2003-2009 &amp; II</a>	Right	8200103263	10
	<a href="#">SC 239</a>	Engine Mount Bushing	<a href="#">RENAULT MEGANE 2003-2009 &amp; II</a> <a href="#">RENAULT SCENIC 2003-2009 &amp; II</a>	Right	8200264322	10

Product Image	Teknorot Ref No	Product Group	Compatible Vehicles	Position	OEM Code	Quantity
	<a href="#">SC 24</a>	Engine Mount Bushing	<a href="#">VOLKSWAGEN GOLF 1983-1992 &amp; MK2/A2</a>	Rear	171199339	10
	<a href="#">SC 240</a>	Engine Mount Bushing	<a href="#">RENAULT KANGOO 2008- &amp; II</a> <a href="#">RENAULT MEGANE 2003-2009 &amp; II</a> <a href="#">RENAULT SCENIC 2003-2009 &amp; II</a>	Right	8200355673	10
	<a href="#">SC 135</a>	Engine Mount Bushing	<a href="#">SKODA FELICIA 1994-2001</a>	Front	7151278	10
	<a href="#">SC 136</a>	Engine Mount Bushing	<a href="#">TOYOTA COROLLA 1997-2002 &amp; E110 Euro Made</a>	Right Upper	1230515040	10
	<a href="#">SC 137</a>	Engine Mount Bushing	<a href="#">VOLKSWAGEN TRANSPORTER 1990-2003 &amp; T4</a>	Front	701399207B*	10
	<a href="#">SC 139</a>	Engine Mount Bushing	<a href="#">RENAULT ESPACE 1996-2002 &amp; III</a> <a href="#">RENAULT LAGUNA 1993-2001 &amp; I</a>	Rear	7700411189	10
	<a href="#">SC 14</a>	Engine Mount Bushing	<a href="#">AUDI 80-90 1974-1981</a> <a href="#">VOLKSWAGEN PASSAT 1974-1981</a> <a href="#">AUDI COUPE 1974-1981</a>	Front	893199381B	10







Product Image	Teknorot Ref No	Product Group	Compatible Vehicles	Position	OEM Code	Quantity
	<a href="#">SC 140</a>	Engine Mount Bushing	<a href="#">RENAULT LAGUNA 1993-2001 &amp; I</a>	Rear	7700817782	10
	<a href="#">SC 141</a>	Engine Mount Bushing	<a href="#">RENAULT LAGUNA 1993-2001 &amp; I</a>	Rear	7700817783	10
	<a href="#">SC 142</a>	Engine Mount Bushing	<a href="#">RENAULT 19 1991-2001</a> <a href="#">RENAULT MEGANE 1991-2001</a>	Front Left	7700801543	10
	<a href="#">SC 145</a>	Engine Mount Bushing	<a href="#">FIAT 131 1974-2001</a>	Front	7593990	10
	<a href="#">SC 146</a>	Engine Mount Bushing	<a href="#">FIAT UNO 1983-2001 &amp; (146A/E)</a>	Rear Left	5974775	10
	<a href="#">SC 147</a>	Engine Mount Bushing	<a href="#">FIAT UNO 1983-2001 &amp; (146A/E)</a>	Left	7622921	10
	<a href="#">SC 149</a>	Engine Mount Bushing	<a href="#">CITROEN JUMPER 1994-2002 &amp; I</a> <a href="#">FIAT DUCATO 1994-2002 &amp; 10Q-14Q-1.8Q</a> <a href="#">PEUGEOT BOXER 1994-2002 &amp; ( 1.4Q-1.8Q )</a>	Left	1307905080, 1827.19	10
	<a href="#">SC 150</a>	Engine Mount Bushing	<a href="#">FIAT DUCATO 1994-2002 &amp; 10Q-14Q-1.8Q</a> <a href="#">PEUGEOT BOXER 1994-2002 &amp; I</a> <a href="#">CITROEN JUMPER 1994-2002 &amp; I</a>	Left	1307908080, 1827.17	10

Product Image	Teknorot Ref No	Product Group	Compatible Vehicles	Position	OEM Code	Quantity
	<a href="#">SC 151</a>	Engine Mount Bushing	<a href="#">FIAT PANDA 1980-2003 &amp; (141A)</a>	Rear	7544663	10
	<a href="#">SC 152</a>	Engine Mount Bushing	<a href="#">CITROEN JUMPER 1994-2002 &amp; I</a> <a href="#">PEUGEOT BOXER 1994-2002 &amp; I</a> <a href="#">FIAT DUCATO 1994-2002 &amp; 100-140-1.80</a>	Rear	1310575080, 1846.65	10
	<a href="#">SC 155</a>	Engine Mount Bushing	<a href="#">CITROEN JUMPER 2002-2006 &amp; II</a> <a href="#">PEUGEOT BOXER 2002-2005 &amp; ( 1.40-1.80 )</a>	Right	1307907080, 1827.19	10
	<a href="#">SC 160</a>	Engine Mount Bushing	<a href="#">OPEL CORSA-COMBO 2000-2006 &amp; C</a>	Rear	684713	10
	<a href="#">SC 17</a>	Engine Mount Bushing	<a href="#">AUDI 100 1976-1990</a>	Left	443199381	10
	<a href="#">SC 179</a>	Engine Mount Bushing	<a href="#">OPEL KADETT 1979-1981 &amp; ( D )</a>	Front	682527	10
	<a href="#">SC 184</a>	Engine Mount Bushing	<a href="#">FIAT IDEA 2003-2012</a> <a href="#">FIAT PUNTO 1999-2009 &amp; 188</a> <a href="#">LANCIA MUSA 2004-2012 &amp; 350</a> <a href="#">LANCIA YPSILON 2003-2011 &amp; 843</a>	Left Lower	46528871	10
	<a href="#">SC 185</a>	Engine Mount Bushing	<a href="#">FIAT IDEA 2003-2012</a> <a href="#">FIAT PUNTO 2005-2018 &amp; GRANDE(199)</a> <a href="#">LANCIA MUSA 2004-2012 &amp; 350</a> <a href="#">LANCIA YPSILON 2003-2011 &amp; 843</a>	Rear	46528865, 46809633	10

Product Image	Teknorot Ref No	Product Group	Compatible Vehicles	Position	OEM Code	Quantity
	<a href="#">SC 188</a>	Engine Mount Bushing	<a href="#">OPEL KADETT 1973-1979 &amp; ( C )</a>	Front	684240	10
	<a href="#">SC 189</a>	Engine Mount Bushing	<a href="#">OPEL ASTRA-ZAFIRA 1998-2004</a>	Rear	5682519, 90538582	10
	<a href="#">SC 195</a>	Engine Mount Bushing	<a href="#">FIAT PUNTO 1999-2009 &amp; 188</a>	Front	46809632	10
	<a href="#">SC 202</a>	Engine Mount Bushing	<a href="#">OPEL CORSA-COMBO 2000-2006 &amp; C</a>	Right	846000	10
	<a href="#">SC 203</a>	Engine Mount Bushing	<a href="#">OPEL CORSA-COMBO 2000-2006 &amp; C</a>	Front	5684172	10
	<a href="#">SC 204</a>	Engine Mount Bushing	<a href="#">OPEL CORSA-COMBO 2000-2006 &amp; C</a>	Left	5684173	10
	<a href="#">SC 205</a>	Engine Mount Bushing	<a href="#">OPEL CORSA-COMBO 2000-2006 &amp; C</a>	Left	5684761	10





Product Image	Teknorot Ref No	Product Group	Compatible Vehicles	Position	OEM Code	Quantity
	<a href="#">SC 206</a>	Engine Mount Bushing	<a href="#">OPEL CORSA-COMBO 2000-2006 &amp; C</a>	Left	5684645	10
	<a href="#">SC 207</a>	Engine Mount Bushing	<a href="#">OPEL CORSA-COMBO 2000-2006 &amp; C</a>	Left	684188	10
	<a href="#">SC 208</a>	Engine Mount Bushing	<a href="#">OPEL CORSA-COMBO 2000-2006 &amp; C</a>	Left	684194	10
	<a href="#">SC 209</a>	Engine Mount Bushing	<a href="#">OPEL MERIVA 2003-2010 &amp; ( A )</a>	Right	684184	10
	<a href="#">SC 210</a>	Engine Mount Bushing	<a href="#">OPEL CORSA-COMBO 2000-2006 &amp; C</a>	Right	5684646	10
	<a href="#">SC 211</a>	Engine Mount Bushing	<a href="#">OPEL CORSA-COMBO 2000-2006 &amp; C</a>	Front Right	684183	10









Product Image	Teknorot Ref No	Product Group	Compatible Vehicles	Position	OEM Code	Quantity
	<a href="#">SC 212</a>	Engine Mount Bushing	<a href="#">OPEL CORSA-COMBO 1993-2000 &amp; (B)</a>	Left	684294	10
	<a href="#">SC 213</a>	Engine Mount Bushing	<a href="#">OPEL CORSA-COMBO 1993-2000 &amp; (B)</a>	Right	684669	10
	<a href="#">SC 33</a>	Engine Mount Bushing	<a href="#">RENAULT MEGANE 1995-2003 &amp; I</a> <a href="#">RENAULT 19 1991-2001</a>	Left	7702253339	10
	<a href="#">SC 34</a>	Engine Mount Bushing	<a href="#">RENAULT 19 1991-2001</a> <a href="#">RENAULT MEGANE 1995-2003 &amp; I</a>	Rear	7700785950, 7700804163	10
	<a href="#">SC 36</a>	Engine Mount Bushing	<a href="#">RENAULT CLIO 1990-1998 &amp; I</a> <a href="#">RENAULT EXPRESS 1990-1998 &amp; I</a>	Front Right	7700805123	10
	<a href="#">SB 421</a>	Engine Mount Bushing	<a href="#">PEUGEOT 106 1991-2004</a> <a href="#">PEUGEOT 306 1991-2004</a> <a href="#">PEUGEOT 206 1991-2004</a>	Front	1807.57	10
	<a href="#">SB 422</a>	Engine Mount Bushing	<a href="#">PEUGEOT 306 1993-2001</a>	Front	1807.57	10


Product Image	Teknorot Ref No	Product Group	Compatible Vehicles	Position	OEM Code	Quantity
	<a href="#">SB 377</a>	Engine Mount Bushing	<a href="#">FORD TRANSIT 1985-1987</a> <a href="#">FORD TRANSIT 1992-2000 &amp; (T12,T15)</a>	Front	6562752, 92VB18016AB	10
	<a href="#">SB 514</a>	Engine Mount Bushing	<a href="#">RENAULT LAGUNA 1993-2001 &amp; I</a>	Rear	7700825795	10
	<a href="#">SB 23</a>	Engine Mount Bushing	<a href="#">VOLKSWAGEN PASSAT 1980-1988 &amp; B2</a> <a href="#">AUDI 80-90 1981-1988</a>	Front	811199415A, 893199415	10
	<a href="#">SB 27</a>	Engine Mount Bushing	<a href="#">AUDI 80-90 1974-1981</a>	Rear	811199419B, 893199419, 811199419C	10
	<a href="#">SC 241</a>	Engine Mount Bushing	<a href="#">RENAULT KANGOO 2008- &amp; II</a> <a href="#">RENAULT SCENIC 2009-2016 &amp; III</a>	Right	8200325283, 8200902956	10
	<a href="#">SC 243</a>	Engine Mount Bushing	<a href="#">FORD ESCORT 1990-2000 &amp; Europe</a>	Rear	6203710	10

Product Image	Teknorot Ref No	Product Group	Compatible Vehicles	Position	OEM Code	Quantity
	<a href="#">SC 246</a>	Engine Mount Bushing	<a href="#">FORD ESCORT 1990-2000 &amp; Europe</a>	Rear Left	6766044, 92AB6P071BA	10
	<a href="#">SC 247</a>	Engine Mount Bushing	<a href="#">FORD FOCUS 1998-2004 &amp; I europe made</a>	Right	1072572, 1S416038BA	10
	<a href="#">SC 25</a>	Engine Mount Bushing	<a href="#">VOLKSWAGEN GOLF 1974-1984 &amp; MK1/A1</a>	Front Left	171199214G	10
	<a href="#">SC 250</a>	Engine Mount Bushing	<a href="#">FORD FOCUS 1998-2004 &amp; I europe made</a> <a href="#">FORD TRANSIT CONNECT 2002-2013 &amp; europe made</a>	Right	1332880, 1M516F012BA	10
	<a href="#">SC 252</a>	Engine Mount Bushing	<a href="#">FORD ESCORT 1990-2000 &amp; Europe</a>	Front Right	6185027, 89FB6038CB	10
	<a href="#">SB 545</a>	Engine Mount Bushing	<a href="#">MERCEDES E-CLASS 1985-1996 &amp; W124</a>	Rear	1243527765	10
	<a href="#">SC 253</a>	Engine Mount Bushing	<a href="#">FORD ESCORT 1990-2000 &amp; Europe (Year Only: 1984-1996)</a>	Front Right	6160229, 86AB6038DB	10
	<a href="#">SC 254</a>	Engine Mount Bushing	<a href="#">FORD ESCORT 1983-1990 &amp; Europe (Year Only: 1984-1996)</a>	Right	6186726, 89AB6038BB	10

Product Image	Teknorot Ref No	Product Group	Compatible Vehicles	Position	OEM Code	Quantity
	<a href="#">SC 26</a>	Engine Mount Bushing	<a href="#">MERCEDES 380SE 1979-1991 &amp; W126</a>	Front	1232413013	10
	<a href="#">SC 264</a>	Engine Mount Bushing	<a href="#">AUDI A3 1996-2003 &amp; 8L1</a> <a href="#">VOLKSWAGEN GOLF 1998-2005 &amp; IV</a> <a href="#">SEAT LEON 1999-2006 &amp; 1M1</a>	Rear Lower	1J0199851AA	10
	<a href="#">SC 265</a>	Engine Mount Bushing	<a href="#">RENAULT CLIO 2005-2010 &amp; III</a> <a href="#">RENAULT SCENIC 2003-2008 &amp; II</a> <a href="#">RENAULT MEGANE 2003-2008 &amp; II</a>	Rear	8200575641	10
	<a href="#">SC 28</a>	Engine Mount Bushing	<a href="#">RENAULT EXPRESS 1985-1998 &amp; EXTRA(VAN)</a> <a href="#">RENAULT CLIO 1990-1998 &amp; I</a> <a href="#">RENAULT 9_11 1981-2000</a>	Right	7704001319	10
	<a href="#">SC 29</a>	Engine Mount Bushing	<a href="#">RENAULT 19 1991-2001</a> <a href="#">RENAULT 9_11 1981-2000</a> <a href="#">RENAULT EXPRESS 1985-1998 &amp; EXTRA(VAN)</a>	Left	7704001320	10
	<a href="#">SC 3</a>	Engine Mount Bushing	<a href="#">VOLKSWAGEN TRANSPORTER 1979-1992 &amp; T3</a>	Front	70199231	10
	<a href="#">SC 30</a>	Engine Mount Bushing	<a href="#">RENAULT 9_11 1981-2000</a> <a href="#">RENAULT EXPRESS 1985-1998 &amp; EXTRA(VAN)</a>	Rear	7700760510	10

Product Image	Teknorot Ref No	Product Group	Compatible Vehicles	Position	OEM Code	Quantity
	<a href="#">SC 31</a>	Engine Mount Bushing	<a href="#">FIAT TEMPRA 1988-1997</a>	Front	7610541	10
	<a href="#">SC 32</a>	Engine Mount Bushing	<a href="#">RENAULT MEGANE 1995-2003 &amp; I</a>	Right	7700785949	10
	<a href="#">ST 91</a>	Engine Mount Bushing	<a href="#">RENAULT CLIO 1998-2012 &amp; II-SYMBOL</a>	Rear	8200175102	10
	<a href="#">ST 114</a>	Engine Mount Bushing	<a href="#">MERCEDES T1 1977-1994 &amp; W601,W602</a>	Right	6012400717	10
	<a href="#">ST 63</a>	Engine Mount Bushing	<a href="#">OPEL ASCONA 1981-1988 &amp; ( C )</a>	Rear	684546	10
	<a href="#">ST 64</a>	Engine Mount Bushing	<a href="#">OPEL ASCONA 1981-1988 &amp; ( C )</a>	Rear	682545	10
	<a href="#">ST 65</a>	Engine Mount Bushing	<a href="#">OPEL VECTRA-CALIBRA 1988-1995 &amp; ( A )</a>	Left	684134	10
	<a href="#">ST 68</a>	Engine Mount Bushing	<a href="#">OPEL ASTRA-ZAFIRA 1998-2004</a>	Front Left	5684045, 5684046	10

Product Image	Teknorot Ref No	Product Group	Compatible Vehicles	Position	OEM Code	Quantity
	<a href="#">ST 70</a>	Engine Mount Bushing	<a href="#">OPEL ASTRA-ZAFIRA 1998-2004</a>	Right	5684054	10
	<a href="#">ST 71</a>	Engine Mount Bushing	<a href="#">OPEL ASTRA-ZAFIRA 1998-2004</a>	Right	5684053	10
	<a href="#">ST 72</a>	Engine Mount Bushing	<a href="#">OPEL ASTRA 1998-2004 &amp; ( G )</a>	Front	684697	10
	<a href="#">ST 73</a>	Engine Mount Bushing	<a href="#">OPEL ASTRA 1998-2004 &amp; ( G )</a>	Front	684692	10
	<a href="#">ST 77</a>	Engine Mount Bushing	<a href="#">OPEL CORSA-COMBO 2000-2006 &amp; C</a> <a href="#">OPEL MERIVA 2003-2010 &amp; ( A )</a>	Front	684238	10
	<a href="#">ST 78</a>	Engine Mount Bushing	<a href="#">OPEL KADETT 1984-1991 &amp; ( E )</a>	Front	684267	10
	<a href="#">ST 79</a>	Engine Mount Bushing	<a href="#">OPEL OMEGA 1994-2003 &amp; ( B )</a>	Front	684173	10
	<a href="#">ST 82</a>	Engine Mount Bushing	<a href="#">OPEL ASTRA 1991-1998 &amp; ( F )</a> <a href="#">OPEL VECTRA-CALIBRA 1991-1998 &amp; ( F )</a>	Front Left	684643, 90372699	10

Product Image	Teknorot Ref No	Product Group	Compatible Vehicles	Position	OEM Code	Quantity
	<a href="#">ST 84</a>	Engine Mount Bushing	<a href="#">OPEL VECTRA 1996-2002 &amp; ( B )</a>	Rear	5682507, 5682511, 5682512, 5682509, 5682508	10
	<a href="#">ST 85</a>	Engine Mount Bushing	<a href="#">OPEL VECTRA 1996-2002 &amp; ( B )</a>	Rear	684703	10
	<a href="#">ST 104</a>	Engine Mount Bushing	<a href="#">VOLKSWAGEN PASSAT 1988-1997 &amp; B3, B4</a> <a href="#">SEAT TOLEDO 1993-1999 &amp; I (1L)</a>	Front	191199279E, 191199279F	10
	<a href="#">ST 74</a>	Engine Mount Bushing	<a href="#">OPEL ASTRA 1998-2004 &amp; ( G )</a>	Front	684693	10
	<a href="#">ST 87</a>	Engine Mount Bushing	<a href="#">OPEL CORSA-COMBO 1993-2000 &amp; ( B )</a>	Front Right	684666	10
	<a href="#">SC 266</a>	Engine Mount Bushing	<a href="#">FIAT EGEA 2015- &amp; 356, TIPO</a>	Front Lower	52026842	10